

# H9 PARTS INSTALLATION INSTRUCTIONS

## MAGAZINE CATCH ASSEMBLY

A basic disassembly must be performed before removing or installing the magazine catch assembly on your H9 pistol. Refer to page 26 of the H9 Operator's Manual for instructions on disassembling the H9. Operate Responsibly, and follow all firearm safety rules and precautions detailed in the manual.

### REMOVAL

1. Use a small flathead screwdriver to turn the slotted head on the magazine catch lock about one quarter of a turn counter-clockwise until the magazine catch assembly loosens in the grip.
2. Guide the assembly through the grip until the small tab on the magazine catch hangs on the inside of the grip. Rotate the assembly about one quarter of a turn and guide the small tab through the opening.
3. Realign the assembly to the keyhole shaped opening, pull the the assembly entirely out of the grip.

### INSTALLATION

1. Hold the magazine catch assembly by the non-textured end. Align the assembly to the keyhole shaped opening on the side of the grip. Insert the assembly into the opening [**see note**], and guide the assembly through the grip until the small tab hangs on the outside of the grip.
2. Rotate the assembly about one quarter of a turn in either direction and guide the small tab through the opening. Realign the assembly to the keyhole opening and fully insert the assembly through the grip.
3. Rotate the slotted head of the magazine catch lock with the small flathead screwdriver one quarter of a turn clockwise to secure the assembly in the grip.

**NOTE:** Install the magazine catch assembly in the right-handed or left-handed orientation according to the your preference. Insert the assembly into the grip from the right hand side for the right-handed orientation or from the left hand side for the left-handed orientation.

