

H9 PARTS INSTALLATION INSTRUCTIONS

THUMB SAFETY PLUGS

A basic disassembly must be performed before removing or installing the thumb safety plugs on your H9 pistol. Refer to page 26 of the H9 Operator's Manual for instructions on disassembling the H9. Operate Responsibly, and follow all firearm safety rules and precautions detailed in the manual.

REMOVAL

1. Complete a basic disassembly. Set the other major components aside.
2. Rotate the left thumb safety plug clockwise with a small flathead screwdriver.
3. Use the screwdriver to pry the left thumb safety plug from the grip assembly, and set the plug aside.
4. Depress the sear and allow the right thumb safety plug to drop freely from the assembly, and set the plug aside.

INSTALLATION

1. Align the left thumb safety plug to the opening behind the engraved company name. Hold the plug in place with your thumb and apply firm pressure.
2. Use a small punch to depress the thumb safety detent plunger behind the plug and depress the plug into the slide until the plug snaps into place.
3. Rotate the left thumb safety plug clockwise with the small flathead screwdriver.
4. Hold the left thumb safety plug in place with your thumb and depress the sear with your index finger until step 6 is complete.
5. Align the right thumb safety plug to the keyhole opening behind the engraved serial number. Insert the narrow end into the grip.
6. Rotate the left thumb safety plug counter-clockwise with your finger or a tool to lock the thumb safety plugs in place. Release the sear.

